

Hitachi Chain Saws
CS 30SB CS 35SB
CS 40SB



HITACHI
Inspire the Next

HITACHI CHAIN SAWS
CS 30SB / CS 35SB / CS 40SB

1,900^{Power Input}**w**
Powerful Motor

for tackling various jobs from pruning
to building a log cabin!



CS 35SB



Built-in Toolless Chain Adjuster!

A large tension dial and knob allow a saw chain to be replaced and tensioned without any tool!

Toolless chain adjuster



Powerful 1,900W Motor

for tackling various jobs from pruning to building a log cabin!

Chain oil flow adjuster

to adjust the chain oil flow rate for auto lubrication.



Power Input
1,900w

CS 30SB



Guide Bar Length
300mm



CS 35SB



Guide Bar Length
350mm



CS 40SB



Guide Bar Length
400mm



Rear handle with soft grip



Mechanical kick-back brake

stops the chain from rotating in case of an unexpected kickback.

Toolless chain adjuster

The large tension dial and knob allow a saw chain to be replaced and tensioned easily without any tool.

SPECIFICATIONS

Model	CS 30SB	CS 35SB	CS 40SB
Voltage	220V, 230V, 240V		
Power Input	1,900W		
No Load Chain Speed	14.5m/s		
Chain Pitch	3/8"		
Chain Gauge	0.05"		
Guide Bar Length	300mm (12")	350mm (14")	400mm (16")
Type of Guide Bar	Sprocket Nose		
Oil Tank Capacity	200mL		
Dimensions (L x W x H)	445 x 270 x 198mm (17-33/64" x 10-5/8" x 7-13/16")		
Dry Weight ^{*1}	4.7kg (10.4lbs.)	4.8kg (10.6lbs.)	4.9kg (10.8lbs.)
Vibration Total Values (triax vector sum) ^{*2}	Vibration emission value ah = 4.0m/s ² Uncertainty K = 1.5m/s ²		
Standard Accessories	Guide Bar, Saw Chain, Chain Saw Oil (100mL), Chain Case		

*1.Weight: According to EPTA-Procedure 01/2003.

*2.The tri-axial vibration value was measured according to EN60745.

Distributed by:

 **Hitachi Koki Co., Ltd.**

www.hitachi-koki.com